

OMVL R90/E Adjustment

OMVL have changed the markings on the casting of their R90/E vaporiser.
This picture has been taken with the solenoid at the bottom (so that the markings can be read).



There are 2 adjusters on the side of the vaporiser – Idle and By-pass.

The one marked Idle is the main sensitivity adjuster. This one protrudes more than the other.

The one marked By-pass is to adjust the mixture at tick-over.